

ARVO-TEC ROBOT FEEDING SYSTEM

- Single feeding unit for up to 199 tanks/feeders.
- The Arvo-Tec Feeding Robot improves feed efficiency and saves labour time.
- One feeding robot supplies many tanks, eliminating the need for a feeder at each tank.
- A high feed turnover rate through the hopper eliminates rancidity and other storage problems. Controlled through local programmer or from a PC.

Options:

- Temperature and Oxygen related feeding with advanced PC control.
- "Light" PC connection.
- MS Windows connection for PC/infra-red or radio communication with robot.
- Automatic refilling system.

Technical Specifications:

- Travel speed 18m/min (6min/100m).
- Battery powered 24 VDC recharges at home-base.
- Optical "eye" to avoid collision.
- 2 feed types in 50L silos.
- Max. rail length 450m / robot, 199 tanks / robot.
- Rail: 80mm steel I, INP80, DIN 1025.
- Feeds whilst moving and spreads feed across the tank.

