

OZONE AND OXYGEN CONCENTRATORS

OZOTECH OZONE GENERATORS

- Patented "Cold Spark" Corona Discharge Technology.
- Fully serviceable.
- The easy way to improve Redox potential.
- Ozotech's patented Cold Spark Corona Discharge out performs the standard corona discharge because of the elimination of heat.
- Easy serviceable screw in tubes. Easily removed and cleaned within minutes to maintain constant performance levels of the generator. All Ozotech ozone tubes carry a 2 year manufacturers warranty.
- All Ozotech Inc. ozone tubes are housed in stainless steel fluted housings for optimum performance and durability.



30281



30292-02

OZ2 MINI & POSEIDON OZONE GENERATORS

- High quality ozone generator for aquarium and research use.
- The OZ2 mini & Poseidon, when compared to other ozone generators in a comparable output, outperform them all. Based on a patented "Cold Spark" technology, the output remains constant for years, is higher in concentration by weight at useable air flow rates, possesses superior quality and workmanship
- Manufactured in the USA.
- Use with air pump or venturi driven skimmers.
- Low maintenance.
- Corrosion resistant.
- Wall mountable.
- Compact size.
- Simple and reliable operation and service.

CODE	DESCRIPTION
30292-01	OZ2 MINI Ozone Generator 220 Vac 50Hz
30281	Poseidon Ozone Generator (with variable output control 1-10)

MODEL	FRONT CONTROL DIAL READING	AIR FLOW LPM	PERCENT OF MAXOUTPUT	MG/HR
OZ2MINI	-	1.41	-	62
OZ2MINI	-	2.1	-	67
OZ2MINI	-	2.5	-	73
POSEIDON	1	2.5	10%	22
POSEIDON	2	2.5	20%	44
POSEIDON	3	2.5	30%	88
POSEIDON	4	2.5	40%	132
POSEIDON	5	2.5	60%	176
POSEIDON	MAX	2.5	100%	220

PCS OZONE GENERATOR SERIES

- Patented "cold spark" corona discharge.
- Lifetime C/D cell warranty.
- Wall mountable.
- Lightweight aluminium chassis
- High reliability.
- Easy to service.

CODE	DESCRIPTION
30010-21	OZ1PC-0.12 up to 0.14 gms/hr
30001-17	OZ2PC-0.21 up to 0.37 gms/hr
30115-03	OZ4AW-0.45 up to 0.90gms/hr
30003-05	OZ8PC-0.62 up to 1.23gms/hr

MODEL	CONC%	AIR FLOW (SCFH)	O2 FLOW (SCFH)	PP PHOENIX (SCFH)	G/HR
OZ1PCS	0.11	-	-	4	0.14
OZ1PCS	0.04	10	-	-	0.12
OZ2PCS	0.20	-	-	6	0.37
OZ2PCS	0.07	10	-	-	0.21
OZ4AW	0.54	-	-	5	0.9
OZ4AW	0.15	10	-	4	0.45
OZ8PC20	0.71	-	-	5	1.23
OZ8PC20	0.21	10	-	4	0.62



OZ1PCS



OZ2PCS



OZ4AW



OZ8AW